

WARNING: Please only perform the following operation if you are experienced in computer troubleshooting. Incorrectly performing this operation could result in permanent damage to the product.

Installing the firmware

- 1. Extract the downloaded ZIP file to your desktop.
- 2. Open your device manager (Press the Windows key + "R" to open the Run window, type in "devmgmt.msc" and press Enter),
 - a. Open the "Universal Serial Bus controllers" section.
 - b. Double click on both of the "Renesas Electronics USB 3.0 Host Controller" items. This is to get the PCI Bus addresses.



- 3. Find the "install.bat" file that you extracted in Step 1. Right click on it and select Edit.
 - a. Verify and/or edit the address information to match what you saw in Step 2.



- 4. Save the file and then move it into the appropriate folder for your operating system version (64 or 32bit).
- 5. Open Windows command prompt, (Win + R, cmd.exe).
- 6. Change to the folder you moved the install.bat file in Step 4 (eg "cd Desktop/Firmware_Update/64bit")
- 7. Type "install.bat" and press Enter.
- 8. You should get a couple of Windows User Account Control requests as the firmware is applied. You will need to agree to both of these prompts.

Verify Update

- 1. Open the device manager (Win + R, devmgmt.msc) and double click on the "Renesas Electronics USB 3.0 Host Controller".
- 2. Under the Advanced tab you see the new firmware version listed there.

